

-----WARNING-----

UNLOAD WEAPON BEFORE INSTALLING OR REMOVING THE REDI-MOD™, FAILURE TO DO SO MAY LEAD TO SERIOUS INJURY OR DEATH! PLACE WEAPON SAFETY ON, REMOVE MAGAZINE, AND CYCLE BOLT TO REMOVE ANY ROUND FROM THE CHAMBER. VISUALLY INSPECT CHAMBER TO MAKE SURE IT IS EMPTY BEFORE PROCEEDING. AFTER INSTALLING SLING, ENSURE THAT ALL CONNECTIONS ARE SECURE BEFORE USING WEAPON.



Contents

1. Redi-mod™
2. Bolt catch extension
3. Gasket
4. Hex wrench

1. Attach bolt catch release extension to the bolt catch release.

Space for the Bolt Catch Release.



Unscrew the two pieces of the bolt catch extension (above) and place around the bolt catch release.(below)



Place the larger piece around the BCR.

Attach the smaller piece to the larger piece

Finger tighten the two pieces together.

2. Open the trigger guard.



Use a cartridge, pen or nail to depress the trigger guard release plunger and swing the trigger guard down to the winter position.

3. Slide the tubular gasket around the mag well.



Most gaskets have a slight taper. The smaller end of the gasket is to be placed in the trigger well.



Slide the gasket around the mag well as shown.



The gasket should fit as shown.



Loosen the screws on the Redi-mod™ to loosen the bracket arms.



Slightly bend the right arm of the clamp out to fit around the lip of the mag well.



Squeeze the two bracket arms together so that the bumper block is touching the left bracket arm.



Tighten the two screws until snug.

Properly installed Redi-mod™.



Properly installed Redi-mod™ with an AR-15 mag in the mag well and one in stand-by in the Redi-mod™.

